

Kaleidoscope

Packaged with your Amiga is a disk labeled "Kaleidoscope." On this disk, you'll find two pieces of free software from Electronic Arts™:

- PolyScope, an electronic kaleidoscope
- SlideShow, a preview of Electronic Arts software for the Amiga

How to Start PolyScope and SlideShow

There are two ways to start PolyScope and SlideShow. If you haven't yet turned on your Amiga:

1. Turn on the Amiga and the monitor or television attached to it.
2. Put the Kickstart disk in disk drive 0 (the disk drive in the main unit of the Amiga).
3. When the picture of a hand holding the Workbench disk appears, remove the Kickstart disk and insert the Kaleidoscope disk.
4. In a few moments, you'll see information about SlideShow and PolyScope. To start the slide show, type "SlideShow" at the keyboard, then press the RETURN key. To start PolyScope, type "PolyScope" at the keyboard, then press the RETURN key.

If you're already using your Amiga:

1. If there's a disk in disk drive 0 (the disk drive in the main unit of the Amiga), take it out of the drive.
2. Put the Kaleidoscope disk in disk drive 0.
3. Make sure the disk drive light is off, then hold down three keys on the keyboard—the CTRL key, the left Amiga key (the key just to the left of the Space Bar) and the right Amiga key (the key just to the right of the Space Bar)—for at least half a second. Release the keys. This resets the Amiga.

NOTE: When you reset the Amiga, you lose any work you have not saved to disk. If you're working on a project, be sure to save what you've done before resetting the Amiga. (For more information about resetting the Amiga, see *Introduction to Amiga*.)

4. In a few moments, you'll see information about SlideShow and PolyScope. To start the slide show, type "SlideShow" at the keyboard, then press the RETURN key. To start PolyScope, type "PolyScope" at the keyboard, then press the RETURN key.

A Note About the PolyScope Instructions

When you start PolyScope, instructions appear on the display. In these instructions, "type 'ESC' " means to press the key labeled ESC at the upper left of the keyboard, while "type <RETURN>" means to press the RETURN key on the keyboard.

How to Stop PolyScope and SlideShow

To stop PolyScope or SlideShow, first make sure the disk drive light is off. Next, reset the Amiga by holding down three keys on the keyboard—the CTRL key, the left Amiga key (the key just to the left of the Space Bar), and the right Amiga key (the key just to the right of the Space Bar)—for at least half a second, then releasing the keys.